

Installation Notes




OnGuard: DCC Circuit Breaker and Autoreverser

Quick Start

Tools Required:

Flat Tip Screwdriver with 1/8" Blade, Wire Strippers.



Connections:

All connections involve two inputs from the DCC booster, or the main line track bus and two outputs to the insulated track section or reverse block.

If your DCC output or mainline track bus is 16 ga or greater (smaller wire) then connect directly to the screw terminals on OnGuard.

If your DCC output or mainline track bus is 10-14 ga wire then solder-splice a short length of 16 AWG to your heavier bus wire and connect the 16 ga wires to screw terminals.

Polarity for Input/Output:

OG-AR: Any input/output polarity is acceptable for OG-AR

OG-CB: Input/output polarity must be the same for all OG-CB installations

DCC Specialties, 210 East Front St., Traverse City, MI 49684

call toll-free 800-671-0641 email info@DCCSpecialties.com

Helpful Hints:

When Isolated and Reverse Sections exceed 10 Ft. in length install at least 2 sets of track feeders for that section. Lack of feeders causes a voltage loss.

For reverse sections, we recommended that the gaps be staggered about 1/8". Perfectly aligned gaps may reduce performance.

If your Power Sections and Reverse blocks are greater than 10 Ft. long be sure to have at least 2 sets of track feeders for that section. Insufficient feeders will cause a voltage drop.

One end of the reverse section will be aligned with normal polarity track power while the opposite or other end will have a polarity mismatch and require the reverser to act.

OnGuard Specifications:

- 4 Amps, suitable for all N, HO and some S, O and G scale applications
- Automatic Reset
- Easy Mount Design at District
- Solid State No Relays
- Optional Status Lights
- Easy to Install
- 1 yr warranty